

Peppermill / Saltmill

085-0005, 085-0007, 050-7150, 085-0010



THE
WOODTURNERS
CATALOG

Craft Supplies USA

BASIC PROCEDURE

(For a fully detailed set of instructions, see turning peppermills by Dale Nish. Item # 186-0100)

Selecting the blank:

Select a 2 3/4" square blank that is 1" longer than the mechanism you have selected.

Mounting the blank:

Mount the blank between center and rough turn to about 2 1/2" in diameter. (see drawing below)

Drilling the blank:

Drill holes for the peppermill (see drawing on back).

- Drill a 1 1/2" diameter hole 3/8" deep into the base of the mill body.
- Drill a 1" hole the rest of the way through the mill body.
- Drill a 1/4" hole through the mill top.

Drill holes for the saltmill (see drawing on back).

- Drill a 1 3/8" diameter hole 3/8" deep into the base of the mill body.
- Drill a 7/8" hole the rest of the way through the mill body.
- Drill a 1/4" hole through the mill top.

Finish turn the blank:

Turn the base and top to the desired shape.

- Turn a 1" spigot (7/8" spigot for saltmill) 1/2" long to fit into the top of the mill body. (see drawing below)

• Peppermill only: Drill an 1/32" diameter recess hole about 3/8" deep to accept the adjustment knob collar (see drawing on back).

Install the mechanism:

Install the mechanism (see mechanism drawing at right).



