

Bowl blank:

- a] 2x2
- b] 3 1/2" or longer

Bowl size:

- a] Turn a cylinder to 1- 3/8 or less but no smaller than 1-1/4".
- b] Mark a line 1-5/16 to 1- 1/4 for the finished length, and start to round over the bottom at the line you marked. Then drill a 1/4" hole about 3/8 " from the top the bowl for the handle to fit into later.
- c] Hollow the bowl to a depth of 1-1/8 to 1- 1/4"
- d] Taper the inside of bowl from the bottom to the top with the top I.D at 1- 1/4 "
- e] you want about a 1/16th" wall thickness at the top of rim

Handle Blank:

- a] 3/4 x 3/4 sq. or 7/8 x 7/8 sq about 6- 1/2" to 7" long.
- b] Using the tail stock for support turn a tapered cylinder down to 1/2".
- c] Put a 1/4" tenon on end of handle ,and then see if the bowl fits on the tenon
- d] With the tail stock in place turn a collar size behind the tenon but not to big so it will fit on the bowl
- e] start making the handle smaller as you make beads, tear drops, etc. remember it is like turning a finial.
- f] sand as you go and the finished length should be 6 to 6-1/2" long ,and now glue the handle to the Bowl.
- g] after the glue is dry reduce and round over the tenon that sticks out inside the bowl, but leave it a little proud.
- h] put a finish on the body and handle, and some oil on the inside of the bowl, then let it dry.