Launcher





1 Begin marking 3/8" line on all 4 sides
2 Then Mark from end 1 1/2" lines on all 4 sides
3 from the 1 1/2" line Mark 3/4" line on both Sided of line on all 4 Sided
4 Find the center on both of the 1 1/2" side and 2" Side
5 Drill 3/8" hole through then the 1" hole through Completely
6 Find the center on each end, use a punch to mark it well,
7 Put it on the Lathe and have fun

Top

Block 2 1/2" x 2 1/2" x 5" long
Find centers on each end
set on to lathe where the point of top is toward tail stock
Cut tennon on head stock end / Place in chuck.

Launcher





1 Begin marking 3/8" line on all 4 sides
2 Then Mark from end 1 1/2" lines on all 4 sides
3 from the 1 1/2" line Mark 3/4" line on both Sided of line on all 4 Sided
4 find the center on both of the 1 1/2" side and 2" Side
5 Drill 3/8" hole through then the 1" hole through Completely
6 Find the center on each end, use a punch to mark it well,
7 Put it on the Lathe and have fun

Top

Block 2 1/2" x 2 1/2" x 5" long
Find centers on each end
set onto lathe where the point of top is toward tail stock
Cut tennon on head stock end / Place in chuck.

Launcher





1 Begin marking 3/8" line on all 4 sides
2 Then Mark from end 1 1/2" lines on all 4 sides
3 from the 1 1/2" line Mark 3/4" line on both Sided of line on all 4 Sided
4 Find the center on both of the 1 1/2" side and 2" Side
5 Drill 3/8" hole through then the 1" hole through Completely
6 Find the center on each end, use a punch to mark it well,
7 Put it on the Lathe and have fun

Top

Block 2 1/2" x 2 1/2" x 5" long
Find centers on each end
set onto lathe where the point of top is toward tail stock
Cut tennon on head stock end / Place in chuck.